


## Air Ionizer Verification Record

Ionizer Verification Sequence Number: 08-122

| WORKING STANDARD USED |               |        |            |                   |                  |                 |
|-----------------------|---------------|--------|------------|-------------------|------------------|-----------------|
| Asset/ISO #:          | Manufacturer: | Model: | Serial No. | Calibration Date: | Calibration Due: | Calibration By: |
| 25171                 | ION           | 775    | 6779       | 8-20-08           | 8-20-09          | JPL             |

| AIR IONIZER INFORMATION |               |            |            |                    |                   |   |
|-------------------------|---------------|------------|------------|--------------------|-------------------|---|
| Asset/ISO #:            | Manufacturer: | Model:     | Serial No. | Verification Date: | Verification Due: | Verification By:  |
| 28974                   | ION           | 6442       | 8839       | 9-24-08            | 11-28-08          |  |
| Inspector:              | Location:     | Owner:     | Fail: Y/N? | Cleaned: Y/N?      | Adjusted: Y/N?    | Prior Sequence#   |
| Minh Do                 | 103/106K      | Patrick F. | N          | N                  | N                 | NA  |

| VERIFICATION DATA   |                                  |                                  |                                   |                                   |           |  |
|---|----------------------------------|----------------------------------|-----------------------------------|-----------------------------------|-----------|--|
| HBM Sensitivity Level: <u>50V</u> (from Table 1)                                      |                                  |                                  |                                   |                                   |           |  |
| Fan controller setting: <u>Low</u> (High, Low, NA)                                    |                                  |                                  |                                   |                                   |           |  |
| Distance of ionizer from the charge plate: <u>24"</u>                                 |                                  |                                  |                                   |                                   |           |  |
| Ionizer Float Potential Tolerance $\pm$ <u>50</u> Vdc. (from Table 1)                 |                                  |                                  |                                   |                                   |           |  |
| Measured Float Potential values recorded below.                                       |                                  |                                  |                                   |                                   |           |  |
| 1<br><br>0 Vdc.   | 2<br><br>0 Vdc.                  | 3<br><br>0 Vdc.                  | 4<br><br>0 Vdc.                   | 5<br><br>0 Vdc.                   | Comments: |  |
| Ionizer Discharge Voltage Range: $\pm$ 1000 Vdc to $\pm$ <u>50</u> Vdc (from Table 1) |                                  |                                  |                                   |                                   |           |  |
| Ionizer Discharge Time Tolerance: <u>520</u> seconds. (from Table 1)                  |                                  |                                  |                                   |                                   |           |  |
| Measured Discharge Time in second(s) and recorded values below.                       |                                  |                                  |                                   |                                   |           |  |
| 1 (+1000 to +Vdc)<br><br>7.3 sec  | 2 (+1000 to +Vdc)<br><br>7.1 sec | 3 (+1000 to +Vdc)<br><br>7.9 sec | 4 (+1000 to +Vdc)<br><br>7.7 sec  | 5 (+1000 to +Vdc)<br><br>7.4 sec  | Comments: |  |
| 1 (-1000 to -Vdc)<br><br>11.1 sec   | 2 (-1000 to -Vdc)<br><br>9.7 sec | 3 (-1000 to -Vdc)<br><br>9.3 sec | 4 (-1000 to -Vdc)<br><br>10.9 sec | 5 (-1000 to -Vdc)<br><br>10.5 sec | Comments: |  |

**Record** any corrective action required to restored ionizer operation (cleaning, adjustment, replacement, etc.)

If Ionizer was replaced, indicate below the identification of replacement.

Asset/ISO #: \_\_\_\_\_ Manufacturer: \_\_\_\_\_ Model: \_\_\_\_\_ Serial No.: \_\_\_\_\_

Sequence number for verification of replacement ionizer: \_\_\_\_\_

**Record** inspection schedule and rational for that schedule.